


Replacement Parts List

Unipower - VA series Models V1 thru V10


VA Series
Installation and Service Manual - 8471-95
Date Code -




VA Models - V1 thru V10 Baffle Configurations

Straights - V1, V2, V3, V5, V7 and V9


Tees - V4, V6, V8 and V10




V1 - 6" Baffle
1405063




V2 - 12" Baffle
1410073




V3 - 18" Baffle
1415058




V4 - 18" Tee Baffle
1420061




V6 - 18" Tee Baffle w/ 6" on Tee
1430058




V5 - 24" Baffle
1425052




V7 - 30" Baffle
1435052



V9 - 36" Baffle
1445051



V8 - 18" Tee Baffle w/ 12" on Tee
1440054



V10 - 2 Tees
1450058



Midco®
INTERNATIONAL


Midco® International Inc.
4140 West Victoria Street
Chicago, Illinois 60646
tel 773.604.8700
fax 773.604.4070
web www.midcointernational.com
e-mail sales@midcointernational.com

AVOID ERROR IN PARTS SELECTION. When ordering use complete MIDCO Part Number and Description. Furnish Burner Model Number, Bill of Material Number and Serial Number (if available) from the specification plate found on the product.

IMPORTANT: Availability of parts as well as specifications are subject to change without notice. Please consult factory for item availability.



Parts Views of - VA Series



Parts List - VA Series

Model Number	V1	V2	V3	V4	V5	V6	V7	V8	V9	V10
Burner - BOM	1405063	1410073	1415058	1420061	1425052	1430058	1435052	1440054	1445051	1450058
Main Valve Train										
1	Man Firing Valve	8404-67	8404-67	8404-66	8404-66	8404-64	8404-64	8404-64	8404-64	8404-64
2	Dungs Low Fire Bypass	8416-14	8416-14	8416-14	8416-14	8416-14	8416-14	8416-14	8416-14	8416-14
3	Dungs Valve	8416-04	8416-04	8416-57	8416-57	8416-58	8416-58	8416-58	8416-58	8416-58
4	Gas Valves	8418-61	8418-62	8418-63	8418-63	8418-64	8418-64	8418-64	8418-64	8418-65
5	Main Valve Train	1405063-010	1410073-010	1415058-010	1420061-010	1425052-010	1430058-010	1435052-010	1440054-010	1445051-010
6	Main Regulator	8416-33	8416-05	8416-05	8416-05	8416-08	8416-08	8416-08	8416-08	8416-11
7	Main Rgltr Sprng	8416-45	8416-06	8416-06	8416-06	8416-09	8416-09	8416-09	8416-09	8416-13
8	Man Gas Shut Off	8404-67	8404-66	8404-65	8404-65	8404-64	8404-64	8404-64	8404-64	8404-64
Pilot Train										
9	Pilot Train	2123-10PA	2123-10PA	2123-10PA	2123-10PA	2123-10PA	2123-10PA	2123-10PA	2123-10PA	2123-10PA
10	Pilot Regulator	8400-00	8400-00	8400-00	8400-00	8400-00	8400-00	8400-00	8400-00	8400-00
11	Pilot Solnd Valve	8402-50	8402-50	8402-50	8402-50	8402-50	8402-50	8402-50	8402-50	8402-50
Burner Housing - Basics and Pilots										
12	Burner Housing	2100-51R	2101-01R	2102-01R	2101-50R	2102-51R	2103-01R	2103-51R	2104-01R	2104-51R
13	Backplate Gasket	8450-30	8450-20	8450-32	8450-33	8450-34	8450-35	8450-36	8450-37	8450-38
15	Pilot Orifice	2112-11 *	2112-11 *	2112-11 *	2112-11 *	2112-11 *	2112-11 *	2112-12	2112-12	2112-12
16	Spark Rod on side	NA	NA	NA	NA	NA	NA	8433-21	8433-21	8433-21
17	Side Pilot	NA	NA	NA	NA	NA	NA	2112-21	2112-21	2112-21
18	UV Scanner	NA	NA	NA	NA	NA	NA	8428-05	8428-05	8428-05
19	Pilot	2112-01	2112-01	2112-01	2112-01	2112-01	2112-01	NA	NA	NA
20	Flame Rod	8433-25	8433-25	8433-25	8433-25	8433-25	8433-25	NA	NA	NA
21	Spark Rod back	8433-24R	8433-24R	8433-24R	8433-24R	8433-24R	8433-24R	8433-21R	8433-21R	8433-21R
22	Mntng Flng Gskt	2122-05	2122-10	2122-17	2122-15	2122-21	2122-20	2122-35	2122-40	2122-45
23	Side Plate	2113-50	2113-50	2113-50	2113-50	2113-50	2113-50	2113-50	2113-50	2113-50
* Models V1 to V 6 Pilot Orifices are not shown										
Blower Assembly										
14	Blower Assmby	2117-13R	2117-10R	2117-30R	2117-30R	2117-30R	2117-30R	2117-40R	2117-40R	2117-40R
Control Assembly										
24	Control Box	2120-16	2120-16	2120-16	2120-16	2120-16	2120-16	2120-17	2120-17	2120-17
25	Wiring Sub Base	8429-16	8429-16	8429-16	8429-16	8429-16	8429-16	8429-16	8429-16	8429-16
26	Flame safeguard	8429-69	8429-69	8429-69	8429-69	8429-69	8429-69	8429-93	8429-93	8429-93
27	Timer	8429-22	8429-22	8429-22	8429-22	8429-22	8429-22	8429-22	8429-22	8429-22
28	Amplifier	8429-27	8429-27	8429-27	8429-27	8429-27	8429-27	8429-30	8429-30	8429-30
29	120V-24V Trnfrm	8447-28	8447-28	8447-28	8447-28	8447-28	8447-28	8447-28	8447-28	8447-28
30	SCEBM-2 Board	8429-78	8429-78	8429-78	8429-78	8429-78	8429-78	8429-78	8429-78	8429-78
31	Termn. Blk 2POS	8409-25	8409-25	8409-25	8409-25	8409-25	8409-25	8409-25	8409-25	8409-25
32	Power Relay	8406-95/98	8406-95/98	8406-95/98	8406-95/98	8406-95/98	8406-95/98	8406-95/98	8406-95/98	8406-95/98
33	Pwr Relay Base	8406-96/99	8406-96/99	8406-96/99	8406-96/99	8406-96/99	8406-96/99	8406-96/99	8406-96/99	8406-96/99
34	Air Switch	8425-56	8425-56	8425-56	8425-56	8425-56	8425-56	8425-56	8425-56	8425-56
35	Power Switch	8423-05	8423-05	8423-05	8423-05	8423-05	8423-05	8423-05	8423-05	8423-05
36	IgntnTransformer	8447-39	8447-39	8447-39	8447-39	8447-39	8447-39	8447-39	8447-39	8447-39
Wires - Not shown										
	Spark Cable	8501-27	8501-27	8501-27	8501-27	8501-27	8501-27	8501-28	8501-28	8501-28
	Flame Rod Wire	8501-20	8501-20	8501-20	8501-20	8501-20	8501-20	8501-20	8501-20	8501-20

Unipower - VA Series - Models V1 thru V10



Midco[®]
INTERNATIONAL

Midco[®] International Inc. - 4140 West Victoria Street - Chicago, Illinois 60646
tel: 773.604.8700 - fax: 773.604.4070 - web: www.midcointernational.com - e-mail: sales@midcointernational.com



1220
8472 96
Printed in USA